



CE SERIES TELEPHONE


INSTALLATION INSTRUCTIONS

All telephones are supplied, wired as shown.

Hookswitch shown with handset "ON" hook.

Common "RING" Terminal 4

Talk "TIP" Terminal 5



**Atlas
Sound**

Specifications are subject to change without notice

AtlasSound.com

1601 JACK MCKAY BOULEVARD ENNIS, TEXAS 75119 U.S.A. • TELEPHONE: (800) 876-3333 • FAX: (800) 765-3435

© 2005 ATLAS SOUND LP

Printed in U.S.A

01105

ATS002231 RevB 11/05

PN 127311



CE SERIES TELEPHONE


INSTALLATION INSTRUCTIONS

All telephones are supplied, wired as shown.

Hookswitch shown with handset "ON" hook.

Common "RING" Terminal 4

Talk "TIP" Terminal 5



**Atlas
Sound**

Specifications are subject to change without notice

AtlasSound.com

1601 JACK MCKAY BOULEVARD ENNIS, TEXAS 75119 U.S.A. • TELEPHONE: (800) 876-3333 • FAX: (800) 765-3435

© 2005 ATLAS SOUND LP

Printed in U.S.A

01105

ATS002231 RevB 11/05

PN 127311